

PROGRAMMING HANDSETS TO NEW CONTROL BOX

- 1) With the power turned onto the unit press and release the small button (learning button) and the yellow LED will come on indicating that you unit is ready to accept a code.
- 2) Press the handset button once. If the code is accepted the green LED will blink twice.
** For multiple handsets code them in at this stage*
- 3) Press and release the small button (learning button) and the yellow LED will go off.

DELETING HANDSETS TO NEW CONTROL BOX

To delete all codes

- » Turn power off
- » Press and hold down the small button (Learning Button) while you turn the power on the 3 LED's will flash twice indicating that all codes have been deleted.

To delete individual codes (you must have the handset that you wish to delete)

- » With the power turned onto the unit press and release the small button (learning button) and the yellow LED will come on indicating that you unit is in learn mode.
- » Press the handset button twice. If the code is deleted the red LED will blink twice.
- » Press and release the small button (learning button) and the yellow LED will go off.